

Information on Disposal of Old Electrical and Electronic Equipment (applicable for EU countries that have adopted separate waste collection systems).



Products with the symbol (crossed-out wheeled bin) cannot be disposed as household waste.

Old electrical and electronic equipment should be recycled at a facility capable of handling these items and their waste byproducts. Contact your local authority for details in locating a recycle facility nearest to you.

Proper recycling and waste disposal will help conserve resources while still preventing detrimental effects on our health and the environment.

OTTO®

1 WIRE MONITORING KIT

Replacement Parts

Description	Part Number
Dynamic Earphone	C101115-2
Clear Ear Tips - QTY 1	C800947
Quick Disconnect Acoustic Tube w/Eartip	C101199
Noise Attenuating Plugs	C100733
Flexible Open Ear Insert, Left	C806573-LM
Flexible Open Ear Insert, Right	C806573-RM

For warranty information, customer service or to order replacement parts, please contact:

OTTO®

10 West Main Street • Carpentersville, IL U.S.A. 60110

Phone: 847-428-7171 • Fax: 847-551-1343

E-mail: info@ottoexcellence.com

www.ottoexcellence.com



- Acoustic Tube Assembly with Rubber Ear Tip
- Miniature PTT

INSTALLATION:

1. Turn the radio off.
Note: Installation of the Monitoring Kit while the radio is on may cause the radio to transmit constantly, locking up your radio system. If this should happen, turn off the radio. The radio can then be turned back on, restoring normal operations.
2. Remove any dust caps or covers from the radio accessory connector.
3. Attach Monitoring Kit to the radio accessory connector.
4. Tighten mounting thumbscrew if required. Install radio accessory clamp if required.
5. The Monitoring Kit can be mounted in either right or left ear.

CAUTION:

Determining the fitness of this product for a specific application or the product's compliance to local, regional, national and international hearing protection standards is the sole responsibility of the user.

OPERATION:

Turn the radio on and operate it as explained in the operating instructions supplied with the radio.

OPERATION:

Turn the radio on and operate it as explained in the operating instructions supplied with the radio. Installing the Monitoring Kit bypasses the radio's speaker and routes the output to the Monitoring Kit's speaker. The in-line push-to-talk (PTT) switch disables the radio's microphone and enables the microphone.

The Monitoring Kit should be placed comfortably in the ear. It can be worn on either right or left ear. The microphone operates with a side-mounted PTT switch and is small enough to fit into the palm and can be concealed by closing the hand. The microphone also has a clip to secure it to a collar of a shirt, jacket, etc.

The Monitoring Kit for Two-Way-Radio communications is intended for use in areas with moderate background noise to provide privacy and noise isolation.

